



# Signal Routing in Delta 1010




Otto Adametz  
 www.alfors.com  
 adametz@alfors.com  
 Delta 1010.cdr  
 11.4.2000



Select output from audio software

Select input into audio software



Output jack on Delta 1010 rack

Input jack on Delta 1010 rack. The routing option HW SPDIF In (L/R Re not shown because it is essentially the same as HW SPDIF In.